INFRARED IMAGING TO QUANTIFY TEMPERATURE CHANGES DURING RAPID MATERIALS DEFORMATION

UCRL-PRES-207962

W.J. Wright, M.W. Burke, W.O. Miller*, and S.J. DeTeresa Manufacturing and Materials Engineering Division *New Technologies Engineering Division

Center for Advanced Signal and Image Sciences Workshop Lawrence Livermore National Laboratory November 18, 2004

This work was performed under the auspices of the U.S. Department of Energy by the University of California, Lawrence Livermore National Laboratory under Contract No. W-7405-ENG-48.



Temperature Measurement and Thermal Analysis to Study the Progressive Stages of Dynamic Failure



During deformation of materials, mechanical work is converted to other forms of energy:



Plastic deformation:

- energy dissipated as heat, eta
- energy stored (e.g., dislocations)
- ∆T~50°-100°C

Shear bands:

- localized plastic deformation
- ∆T~500°C (phase change)

Fracture:

- energy consumed by free surfaces
- microfracture





Intermediate and High Strain Rate Uniform Deformation



ENGINEERING





Intermediate Strain Rate: 10 s⁻¹ High Strain Rate: 3000 s⁻¹

Materials of Interest: Pure Tantalum and Kel–F

•Reported values of ß range from 0.6 – 1.0



Available Temperature Measurement Techniques



Contact Measurement Sensors

- Well-calibrated
- Finite response time
- Point measurement
- May influence sample temperature

Infrared Sensors

- Remote temperature measurement
- Improved response time (250 nanoseconds possible)
- Full field measurement possible
- Gradients easily detected
- Every material of interest must first be calibrated due to differences in emissivity

 $\mathcal{E} + \mathcal{R} = 1$ $\frac{\mathcal{E}}{\mathcal{R}}$

 $\mathcal{E} = \text{emissivity}$ $\mathcal{R} = \text{reflectivity}$





Available Technology for Dynamic Infrared Temperature Measurement

Phoenix InSb

- Full field sensing
- 640 x 512 pixels @ 100 Hz, 128 x 12 pixels @ 10 kHz, currently using 128 x 76 pixels @ 2 kHz
- 25 µm resolution
- 3–5 μ m MWIR
- Built-in optics

Fermionics HgCdTe

- 250 ns rise time, multi-frame
- 16 detectors in linear array, 80 x 80 μm spot size, 20 μm spacing
- 8–12 µm LWIR
- Cassegrain optics
- Single point temperature measurement using fast response thermocouples (~2°C/µs – M.M. LeBlanc)
 - For work in uniform plastic deformation (no gradients)





Fermionics HgCdTe





Experimental Issues in Infrared Temperature Measurement



- Ideally calibration conditions are identical to test conditions
- Surroundings contribute an infrared signal therefore, want extraneous sources hidden or removed from view
- Emissivity is different for each material and varies as a function of surface treatment
- Emissivity may change during mechanical deformation due to evolution in surface texture or surface oxidation
- Narcissus effect and optical vignetting
- Lens heating during static calibration
- Cylindrical versus cubic samples





Emissivity and Surface Texture





- Calibrations were highly repeatable and followed expected trends
 - No evidence that emissivity changed with exposure to these temperatures
- Surface texture was modified to increase emissivity
- High emissivity coatings gave mixed results
 - Higher emissivity, but problems with coatings flaking off during dynamic deformation





Emissivity and Environment





- Calibrations performed in air and vacuum (75 mTorr) under otherwise identical conditions
- There is a small, but repeatable difference between air and vacuum, but not sufficient to account for published discrepancies in β
- Mock High Explosive (HE) yields high signal





Numerical modeling is used to determine when adiabatic conditions are met in uniform deformation



- LS-DYNA was used to simulate a uniaxial compression test with annealed tantalum
- Model includes plastic work-to-heat conversion and surface heat transfer to surroundings
- A 1/8 symmetry model was developed for a specimen that was plastically deformed to 15% true strain
- Deformation time of 15 ms (strain rate = 10 s⁻¹) was used to determine effect of rate on surface heat loss







Results show that adiabatic conditions prevail away from specimen ends during intermediate rate deformation



ENGINEERING



10 s⁻¹ strain rate shows 46 °C average temperature rise, cooling to 42 °C at anvil contact surface

Can compare IR and thermocouple measurements for intermediate rate tests



Preliminary Results for Annealed Tantalum









Emissivity increases with strain as surface texture changes











- Our goal is to use infrared thermography to study dynamic deformation and failure of materials.
- Material emissivity is the most challenging experimental issue when determining the absolute temperature of an object.
- IR thermography is a powerful materials and process characterization tool.



